

Weller[®] FT

FILTER SYSTEMS



Zero Smog 4V / Zero Smog 6V
Zero Smog 20T

原装使用说明



致力于电子测试、维护领域!




Zero Smog 4V

T0053660699



T0058735938
F7




T0058735936

Zero Smog 6V

T0053666699



T0058735836
F7




T0058735838

Zero Smog 20T

T0053670699




T0058735836
F7



T0058735838

Zero Smog 4V, Zero Smog 6V, Zero Smog 20T



1


红/黄/绿 过滤器调节

2

RS232 接口

3

USB 接口









4 有声信号

5 菜单键


6 开关按钮

Zero Smog 4V / 6V












Tip








Zero Smog 20T








Zero Smog 20T

TIP











Zero Smog 4V



4D6R1051
Zero-Smog 4V

Zero Smog 6V



3D9R1091 Zero Smog 6V